

Tredit™

Torque Specifications

Using a properly calibrated torque wrench, all the lug nuts installed with any new tire/wheel assembly must have their torque values checked after the first 10, 25, and 50 miles (and periodically checked during normal use thereafter). This process should be repeated any time that the lug nuts are removed from the wheel.

| Size | Bolt Circle | Off Set | Recommended Torque (ftlbs) | |
|--------------------|--------------|---------|----------------------------|----------|
| | | | Steel | Aluminum |
| 12" | 4-4 or 5-4.5 | 0.00 | 50-75 | 95-105 |
| 13" | 4-4 or 5-4.5 | 0.00 | 50-75 | 95-105 |
| 14" | 5-4.5 | 0.00 | 90-120 | 110-120 |
| 15" | 5-4.5 | 0.00 | 90-120 | 110-120 |
| 15" | 6-5.5 | 0.00 | 90-120 | 110-120 |
| 16" (1/2" Stud) | 6-5.5 | 0.00 | 90-120 | 110-120 |
| 16" (9/16" Stud) | 8-6.5 | 0.00 | 90-120 | 125-130 |
| 17.5" (9/16" Stud) | 8-6.5 | 0.00 | N/A | 125-130 |
| 17.5" (5/8" Stud) | 8-6.5 | 0.00 | 275-325 (Flange Nut) | 150 |

*Always verify installation recommendations, procedures, and tolerances with all other running gear component(s)

Lug Nut Installation Sequence(s)

